


## KEYS LAYOUT AND OPERATION

### FIXED FUNCTIONS KEYS

<b>Phone</b>	Display Phone screen	<b>Messages</b>	Access
<b>Services</b>	Open Settings Menu	<b>Call Log</b>	Access log of calls dialed & received
<b>Speaker</b>	Activate/ Deactivate Speakerphone	<b>Directory</b>	Access Phone Directory
<b>Headset</b>	Activate/ Deactivate the Headset	<b>Forward</b>	Call Forwarding control & options
<b>Vol. +</b>	Increase the volume	<b>Conference</b>	Establish a conference call
<b>Vol. -</b>	Decrease the volume	<b>Transfer</b>	Transfer a call
<b>Mute</b>	Deactivate/ Activate the microphone	<b>Hold</b>	Place a call on hold

### NAVIGATION KEYS



## DISPLAY ICONS OVERVIEW

### DISPLAY ICONS IN IDLE STATE

Icon	Description
	You have one or more new missed calls
	Call Forwarding is active for all incoming calls
	You have one or more new messages

### DISPLAY ICONS DURING A CALL

Icon	Description
	You are on an active call
	Your call has been disconnected
	You placed the call on hold
	The other party placed the call on hold

### DISPLAY ICONS WHEN FEATURE IS ACTIVATED

Icon	Description
	The Do Not Disturb function is active
	The Ringer is turned off

### CONTEXT SENSITIVE SOFT KEYS



# VOICE OVER IP DESK PHONE

## Quick Reference Guide



VoIP Desk Phone IP 55G

